

# MVP AND TCODE PRO

Powered by *ADVANCED DIAGNOSTICS USA*

## DODGE 2013

(ADS-195)

- 2013 DODGE DART & RAM  
FOBIK



- 2013 DODGE DART & RAM  
PROXIMITY



4-DIGIT PIN CODE IS REQUIRED.

**There is NO PIN CODE READING available  
for these new systems at this time.**

*(Optional software on TCode PRO units)*

# MVP AND TCODE PRO

Powered by *ADVANCED DIAGNOSTICS USA*

## **MVP User's Note:**

Once you connect to the vehicle and get security access (Web or SMC) you can go in and erase and program as many FOB/PROXIMITY keys as the vehicle allows and use only one token.

On these new systems you must have the pin code. There is NO pin code reading at this time.

If you unplug you have to get security access again and will use more tokens.

## What You Need To Program Keys

### *MVP & TCODE PRO*



or



U.S. Patent #7315238

+



## PIN

**4-DIGIT MANUFACTURERS PIN  
CODE IS NEEDED**



+

**Smart Card Calculator or Web  
Challenge if tester does not  
have SMC.**

## DONGLE



**G-Tan**

**Fobik/Proximity Key Programming**

# DODGE 2013 DART AND RAM FOBIK

## Keys to Use



FOBIK w/o remote start

OEM 56046773AA

NEW part numbers for 2013 Dodge  
Dart & Dodge RAM FOBIK

Check with dealer for the correct part  
number to use depending on what  
options your vehicle is equipped.



FOBIK w/ remote start

OEM 56046771AA



The mechanical emergency key  
slides into the back of the remote  
just like on previous versions of  
FOBIK KEYS.

The key has no transponder in it.



Some baseline models  
do not come equipped  
with electric locks and  
windows these just use  
a "POD KEY"

Strattec 5909874  
will substitute for the  
OEM POD KEY and can  
also be used in place  
of the FOBIK KEYS  
shown above

## DODGE 2013 DART AND RAM KEYS



### *Important note about these keys....*

ALL 2013 Dodge Dart and Ram FOBIK KEYS  
“LOCK” once used on a vehicle can and can  
NOT be re-used on any other vehicle.

Keys can be erased and then re-used on  
that same vehicle if you want, but never on  
a different vehicle.

For this reason be very careful when  
purchasing keys.

Our testing showed the following on the  
DART and RAM Proximity keys...

1. The DART Prox system will accept a used  
proximity key. A used one for 2011+ Charger,  
300M or Journey will substitute.



2. The Dodge RAM system will NOT accept  
the 2011+ Charger, 300M or Journey Key and  
only accepted a brand NEW key.  
OEM Part No. 56046956AC.  
(No photo available at this time)



# DODGE 2013

**Use this method to PROGRAM FOBIK KEYS**



VEHICLE SELECTION	
+ALFA	+HONDA/ACURA
+AUDI	+HYUNDAI
+BENTLEY	+INFINITI
+BMW	+ISUZU
+CADILLAC	+IVECO
+DODGE	+JAGUAR

PRESS ENTER KEY

From the "VEHICLE SELECTION" menu, select "+DODGE". Press the ENTER key. *Note: Other vehicle selections may vary depending on software on your unit*

VEHICLE SELECTION	
+IMMOBILIZER	
+REMOTE	
+SKIM READING	

PRESS ENTER KEY

Select "+IMMOBILIZER". Press the ENTER key.

VEHICLE SELECTION	
+BY VEHICLE	
+BY SYSTEM V1	
+BY SYSTEM V2	

PRESS ENTER KEY

Select "+BY VEHICLE". Press the ENTER key.

VEHICLE SELECTION	
+CHARGER	
+DAKOTA	
+DART	
+GRAND CARAVAN	
+RAM	

PRESS ENTER KEY

OR

VEHICLE SELECTION	
+CHARGER	
+DAKOTA	
+DART	
+GRAND CARAVAN	
+RAM	

PRESS ENTER KEY

Based on the vehicle, select either "+DART" or "+RAM". Be careful, they are not the same. Press the ENTER key.

VEHICLE SELECTION	
+ BASELINE FOBIK	
+PROXIMITY	

PRESS ENTER KEY

Select "+BY VEHICLE". Press the ENTER key.

# DODGE 2013

*Use this method to PROGRAM FOBIK KEYS*

## ECU IDENTIFICATION

HAZARDS ON / IGNITION OFF

PRESS ENTER KEY

Switch the vehicle's hazard lights "ON".

Leave the ignition in the "OFF" position.

Press the ENTER key.

## VEHICLE SELECTION

1C3CDFBA8DD1234567  
PART No. 65046808AD

KEYS PROGRAMMED : 4

PRESS ENTER KEY

The vehicle's VIN number the part number for the ECU and the total number of keys programmed should display.

Press the ENTER key.

## DIAGNOSTICS MENU

ECU IDENTIFICATION  
FAULT CODES  
> SPECIAL FUNCTIONS

PRESS ENTER KEY

Move the selection pointer > to SPECIAL FUNCTIONS.

Press the ENTER key.

## VEHICLE SELECTION

> PROGRAM KEYS  
ERASE KEYS  
SHIPPING MODE OFF

PRESS ENTER KEY

Move the selection pointer > to PROGRAM KEYS.

Press the ENTER key.

## VEHICLE SELECTION

ARE YOU SURE

X

✓

Press the CHECK MARK ✓ TO PROCEED  
or  
X TO GO BACK.

Make sure you have an UNPROGRAMMED key in the ignition.

Leave the ignition in the OFF position.

# DODGE 2013

**Use this method to PROGRAM FOB/KEYS**



SECURITY CODE				
----				
1	2	3	4	5
6	7	8	9	0

Using the touch screen carefully enter the vehicle's unique 4-digit PIN CODE. You cannot proceed without the correct code for the car you are working on.

SECURITY CODE	
1 2 3 4	
(EXAMPLE)	
X	✓

The code you have entered will be displayed.

Press the CHECK MARK ✓ TO PROCEED  
or  
X TO GO BACK & RE-ENTER a different code.

PROGRAM KEYS
PLEASE WAIT
*****
PRESS ENTER KEY

Based on the vehicle, select either "+DART" or "+RAM". Be careful, they are not the same. Press the ENTER key.

PROGRAM KEYS
KEYS PROGRAMMED : 3
PRESS ENTER KEY

In this example, there were two keys programmed before the PROGRAM KEY PROCEDURE was used. The PRO should now display "KEYS PROGRAMMED: 3". Repeat this procedure for any additional keys you want to program. (Maximum eight keys total.)

# DODGE 2013

**Use this method to ERASE FOBIK KEYS**

## TROUBLESHOOTING SECTION

### DISPLAY FAULT CODES

MIS MATCHED ECU  
MIS MATCHED RFH HUB

PRESS ENTER KEY

If any of the vehicles immobilizer components have been swapped or replaced a dealer OEM tool will be required to MATCH components.

### PROGRAM KEYS

PLEASE WAIT

\*\*\*\*\*

If the PLEASE WAIT SCREEN takes too long and does not change then check the key. It is either an already programmed key or is incorrect.

INCORRECT PIN CODE

If you receive this message after entering the PIN CODE this means either the PIN CODE is INCORRECT or the IMMOBILIZER is "LOCKED".

### DIAGNOSTICS MENU

ECU IDENTIFICATION  
FAULT CODES  
> SPECIAL FUNCTIONS

PRESS ENTER KEY

Move the selection pointer > to SPECIAL FUNCTIONS.  
Press the ENTER key.

### VEHICLE SELECTION

PROGRAM KEYS  
> ERASE KEYS  
SHIPPING MODE OFF

PRESS ENTER KEY

Using ERASE KEYS is OPTIONAL on this system.

You DO NOT have to ERASE KEYS.

Use ERASE KEYS only if you want to CLEAR all previously programmed keys from memory.

### VEHICLE SELECTION

ARE YOU SURE

X

✓

Press the CHECK MARK ✓ TO PROCEED  
or  
X TO GO BACK.

Make sure you have an UNPROGRAMMED key in the ignition.

Leave the ignition in the OFF position.



# DODGE 2013

**Use this method to ERASE FOB/KEYS**

SECURITY CODE				
----				
1	2	3	4	5
6	7	8	9	0



SECURITY CODE				
1 2 3 4				
(EXAMPLE)				
X				✓

Using the touch screen carefully enter the vehicle's unique 4-digit PIN CODE. You cannot proceed without the correct code for the car you are working on.

The code you have entered will be displayed.

Press the CHECK MARK ✓ TO PROCEED  
or  
X TO GO BACK & RE-ENTER a different code.

ERASE KEYS	
PLEASE WAIT	
*****	
PRESS ENTER KEY	

"PLEASE WAIT" should display and stars will begin to move across the screen as the PRO erases ALL keys.

ERASE KEYS	
KEYS PROGRAMMED : 0	
PRESS ENTER KEY	

Next go back to the SPECIAL FUNCTIONS MENU & follow the PROGRAM KEYS PROCEDURE to program keys back into the system.

# DODGE 2013

*Use this method to ERASE PROX KEYS*

## DIAGNOSTICS MENU

ECU IDENTIFICATION  
FAULT CODES  
> SPECIAL FUNCTIONS

PRESS ENTER KEY

Select the vehicle you are working on for example:  
+DODGE / + BY VEHICLE / +DART / PROXIMITY / SPECIAL FUNCTIONS.

Press the ENTER key.

## VEHICLE SELECTION

PROGRAM PROX  
> ERASE PROX  
SHIPPING MODE OFF

PRESS ENTER KEY

Using ERASE PROX is OPTIONAL on this system.

You DO NOT have to ERASE KEYS.

Use ERASE KEYS only if you want to CLEAR all previously programmed keys from memory.

## ERASE PROX

ARE YOU SURE

X

✓

Press the CHECK MARK ✓ TO PROCEED  
or  
X TO GO BACK.

Leave the ignition in the OFF position.

## SECURITY CODE

----

1

2

3

4

5

6

7

8

9

0

Using the touch screen carefully enter the vehicle's unique 4-digit PIN CODE.

You cannot proceed without the correct code for the car you are working on.

## SECURITY CODE

1 2 3 4

(EXAMPLE)

X

✓

The code you have entered will be displayed.

Press the CHECK MARK ✓ TO PROCEED  
or  
X TO GO BACK & RE-ENTER a different code.

# DODGE 2013

***Use this method to ERASE PROXIMITY KEYS***

ERASE PROX
PLEASE WAIT *****
PRESS ENTER KEY

"PLEASE WAIT" should display and stars will begin to move across the screen as the PRO erases ALL PROX.

ERASE PROX
PROX PROGRAMMED : 0
PRESS ENTER KEY

Next go back to the SPECIAL FUNCTIONS MENU & select the PROGRAM PROX PROCEDURE to program PROX keys into the system.

## ***WARNING!***

Our testing has shown a Catch22 style DESIGN FLAW in the DODGE PROXIMITY SYSTEMS.

DO NOT ERASE PROXIMITY KEYS IF THE VEHICLE IS IN SHIPPING MODE!

Proximity keys CANNOT be programmed if the vehicle is in SHIPPING MODE.

The vehicle cannot be taken out of shipping mode without a WORKING PROXIMITY KEY!  
(even with dealer equipment)

# DODGE 2013

*Use this method to PROGRAM PROX KEYS*

## DIAGNOSTICS MENU

> PROGRAM PROX  
ERASE PROX  
SHIPPING MODE OFF

Select the vehicle you are working on for example: +DODGE / + BY VEHICLE /  
+DART / PROXIMITY / SPECIAL FUNCTIONS / PROGRAM PROX

Press the ENTER key.

## SECURITY CODE

----

1	2	3	4	5
6	7	8	9	0

Enter the PIN CODE.

## SECURITY CODE

1 2 3 4

(EXAMPLE)

X

✓

The code you have entered will be displayed.

Press the CHECK MARK ✓ TO PROCEED  
or  
X TO GO BACK & RE-ENTER a different code.

## PROGRAM PROX

FOLLOW THE NEXT SCREEN  
CAREFULLY  
COMPLETE OPERATIONS  
WITHIN 60 SECONDS  
AFTER PRESSING ENTER

PRESS ENTER KEY

Have all the PROXIMITY keys inside the vehicle and ready.

Press ENTER key.

## PROGRAM PROX

HOLD PROX NEAR CENTER  
CONSOLE  
PRESS AND RELEASE THE  
UNLOCK BUTTON ON PROX  
6 TIMES  
THEN PRESS LOCK BUTTON  
ON PROX ONCE.

The code you have entered will be displayed.

Press the CHECK MARK TO PROCEED or  
X TO GO BACK TO RE-ENTER a different code.

# DODGE 2013

## *PROGRAM PROXIMITY KEYS - Cont'd*

### PROGRAM KEYS

PROCEDURE COMPLETE

PROX PROGRAMMED : 3

The last screen should display the total number of PROX keys programmed.

# DODGE 2013

## EXIT SHIPPING MODE - Cont'd

### DIAGNOSTICS MENU

ECU IDENTIFICATION  
FAULT CODES  
> SPECIAL FUNCTIONS

Pick the make and model.

Select: SPECIAL FUNCTIONS.

Press the ENTER key.

### DIAGNOSTICS MENU

PROGRAM KEYS  
ERASE KEYS  
> SHIPPING MODE OFF

Select: SHIPPING MODE OFF

### SHIPPING MODE OFF

SWITCH IGNITION ON

**CAUTION:** The ignition must be switched "ON" in order to exit shipping mode. This is no problem on FOB/K models, however, on PROX models if NO WORKING PROX is available the ignition CANNOT be switched "ON"  
Prox cannot be programmed while the vehicle is in shipping mode. This is a CHRYSLER catch 22. If all PROX are lost or erased while in shipping mode the BCM module will need to be replaced!

PRESS ENTER KEY

### SHIPPING MODE OFF

PROCEDURE COMPLETE

The vehicle should now be out of SHIPPING MODE.

Press the ENTER key to return to the special functions menu.

PRESS ENTER KEY

# DODGE 2013

*Use this method to CLEAR DTC's*



## DIAGNOSTICS MENU

ECU IDENTIFICATION  
FAULT CODES  
> SPECIAL FUNCTIONS

Move the selection pointer > to FAULT CODES.

Press the ENTER key.

## DIAGNOSTICS MENU

> READ FAULT CODES  
CLEAR FAULT CODES

To READ FAULT CODES:

Move the selection pointer > to READ FAULT CODES.  
Press the ENTER key.

## DISPLAY FAULT CODES

NO FAULT CODES FOUND

FAULT CODES will be displayed. In this example NO fault codes are present.  
Press the ENTER key.

PRESS ENTER KEY

## DIAGNOSTIC MENU

READ FAULT CODES  
> CLEAR FAULT CODES

To CLEAR FAULT CODES:

Move the selection pointer > to CLEAR FAULT CODES.

Press the ENTER key.

## PROGRAM PROX

HOLD PROX NEAR CENTER  
CONSOLE  
PRESS AND RELEASE THE  
UNLOCK BUTTON ON PROX  
6 TIMES  
THEN PRESS LOCK BUTTON  
ON PROX ONCE.

All immobilizer system fault codes have been cleared.

If you read fault codes again and any re-appear there is a problem in the system.  
Press the ENTER key.

# DODGE 2013

## *CLEAR DTC's - Cont'd*

CLEAR FAULT CODES

PROCEDURE COMPLETE

PRESS ENTER KEY

All immobilizer system fault codes have been cleared.  
If you read fault codes again and any re-appear there is a problem in the system.

Press the ENTER key.